

Robot

Roomba

Vacuuming Robot

The iRobot® Roomba® 800 Series features the AeroForce® 3-Stage Cleaning System and Tangle-Free Extractors for improved cleaning performance and lower maintenance. Just press CLEAN on the robot, or start and schedule Roomba on the go with the iRobot HOME App.¹



SMART

iAdapt® Navigation enables Roomba® to vacuum an entire room, cleaning under furniture, around obstacles and along wall edges.

- Full suite of sensors and low profile design enable Roomba to navigate under furniture and around clutter.
- At just 3.6" (9.2 cm) tall, Roomba has been specifically designed to fit under most furniture and kickboards, so dirt has no place to hide.
- Roomba detects high concentrations of dirt and debris and spends more time cleaning those areas.
- Cliff-detection sensors allow Roomba to avoid stairs.

SIMPLE

Just press CLEAN on the robot or in the iRobot HOME App¹ and brushless extractors will help prevent tangles and jams caused by hair and other debris, making it even easier to tackle the daily build-up of dust and dirt.

- With just the press of a button, Roomba gets to work with no programming required.
- Roomba automatically adjusts to clean carpets, tile, hardwood and laminate floors as it moves through your home.
- The iRobot HOME App¹ lets you clean and schedule conveniently, see the status of cleaning jobs no matter where you are, and gives you direct access to customer support.
- Using the iRobot HOME App,¹ Roomba can be preset to vacuum up to seven times per week, meaning your home can stay clean every day.
- Roomba has an indicator on the robot and in the iRobot HOME App¹ to let you know when the bin is getting full and needs to be emptied.
- With Amazon Alexa or the Google Assistant, you have hands-free control to start, stop, or dock your Roomba® 890 vacuuming robot.³

CLEAN

The AeroForce® 3-Stage Cleaning System for improved cleaning performance and lower maintenance uses a balance of agitation, debris extraction and suction power.

- Up to 5x the air power with the Gen 2 motor.²
- Spinning side brush sweeps wall edges and corners, pushing debris into the path of the 3-Stage cleaning system.
- Roomba is always ready to clean because it always returns to its Home Base® between cleanings to recharge.



¹The iRobot HOME App is only available for select Roomba 800 series models with Wi-Fi connectivity. ²Compared to Roomba® 600 and 700 series AeroVac™ systems.

³Compatible with Wi-Fi® connected Roomba® vacuuming robots only.